

# Instructions for use

## Gold on Roll Device

To make the device ready for use, remove the two adjusting screws, the spring, and the cover plate. Then place the unopened gold roll (X) on the middle axle (A). Place a guide roll (Z) that exactly matches the width of the gold roll on the front axle (B); these are included in various widths.

Then reinsert the cover plate (D) into the device and place the spring (F) on the axle (A) and an adjusting screw (E) on each axle. Tighten the screws until the cover plate (D) is under slight pressure. Only now should you open the paper feed of the gold roll (X) using a pointed object, pull the paper strip out between the two rolls, and carefully stick it onto the opposite side of the guide roll (Z).

Now roll the protective paper layer of the gold roll onto the guide roll by moving it across the work table. Adjust the adjusting screws so that the rollers turn with the desired ease. As soon as the gold appears on the paper strip, gilding can begin. It is important to ensure that the entire width of the roller touches the object to be gilded with light and even pressure so that the empty paper that has been wound onto the roller cannot slip.

If the empty paper wraps crookedly onto the guide roller, reattach it. When the Gold on Roll Device is not in use, tighten the adjusting screws so that the roller cannot turn.

